

PERSONAL VIDEO RECORDER (PVR) QUICK TOUR

You are about to enjoy the pleasure and convenience of an advanced satellite TV receiver with an integrated Personal Video Recorder!

A **Personal Video Recorder (PVR)** lets you customize the way you watch television. With PVR, you can record and play back audio and video with full digital quality. You can pause a live program and not miss any of the action or you can record a program to watch later, without a VCR.

QUICK TOUR OF THE PERSONAL VIDEO RECORDER

Remote Buttons

Menu Options

1. Make sure the receiver is turned on, with the green front panel **Power** light on. To do this, press the remote control's blank **Power** button. *Also, make sure the TV is turned on.*



2. Press the **View** button to make sure you see a program.



3. Watch the program for just a few minutes.



4. Press the **Pause** button to pause the program.



Notice the pause symbol and the timer that shows how long you have paused (*only* for "live" programs, not recorded programs).



Press the PAUSE button and then press the BACK button to reverse the program in slow motion. Press the BACK button once to reverse the program 1/4 the speed as normal play. Press the BACK button twice to reverse at normal speed.



Press the PAUSE button and then press the FWD button to forward the program in slow motion. When you press the FWD button once the program advances at 1/15 the speed of normal play. Press the FWD button twice to forward at 1/4 as fast as normal play. Press the FWD button three times to play the program.

User Guide

5. Press the **Play** button to watch the program *from the place where you paused it.*



Notice the play symbol on the TV screen. It disappears after a few seconds.

6. Press the **View** button to go back *right away* to the “live” program.



You can *always* go right back to the “live” program.

7. Press the **Reverse (Back)** button to rewind the program.



You can watch a key play or exciting scene *again!*

Notice the rewind symbol and the bar that shows how far you have rewound the program.



8. Press the **Skip Back** button to skip back through the program.



Notice the skip back symbol on the TV screen. It disappears after a few seconds.



9. Press the **Forward (FWD)** button to fast forward the program.



Notice the fast forward symbol and the bar that shows how far you have forwarded the program. Of course, you *cannot* forward into the part of a “live” program not yet broadcast - but you can forward into *any* part of a recorded program.



10. Press the **Skip Ahead** button to skip ahead through the program.



Notice the skip ahead symbol on the TV screen. It disappears after a few seconds.



11. Press the **View** button to go back *right away* to the “live” program.



Using The System

Personal Video Recorder (PVR) Quick Tour

3

12. Press the **Record** button to start recording the program *right now*. The receiver will record all of the program *from this time on*.



Notice the receiver's front panel **Recording** light turns on to show you are recording.



13. *If you want to take the time*, use the **Program Guide** to tune to a program set to start in the next few minutes. *At the start of the program*, press the **Record** button to record the program *while you watch it*.



14. *If you want*, you can use the pause, play, reverse, skip back, forward, or skip ahead features *at the same time* as the receiver records the program from start to finish.

You can watch a program *any way you want*, while the receiver takes care of recording it!

15. *If you want*, press the **Stop** button. This stops the receiver from recording the program.



Notice the receiver's front panel **Recording** light turns off to show you have stopped recording.



When you press the **Record** button to record, *you* control how long the receiver records. So, the receiver will *not* stop recording too soon. Of course, this also means *you must* remember to stop the recording.

16. *Now, if you want to take the time*, use the **Program Guide** to find another program set to start in the next few minutes.

This is important: Start watching the program when it starts. Watch the program for a few minutes.

17. Press the **Reverse (Back)** button to rewind this program.



This is important: Let the program rewind *all the way to its start*.

18. Press the **Record** button.

Right away, the receiver stores a recording of *all* of the program as it has been broadcast so far, *and keeps on recording* the program. So, you can record *all of the program, even though* you did not *start* recording until *after* the program started.



You can record *all* of a program, up to about an hour *after* it has started!


This is important: If you did *not* tune the receiver to a program until *after* it started, you could record *only* the part of the program *that came after you tuned the receiver to it.*

19. *If you want*, you can use the pause, play, reverse, skip back, forward, or skip ahead features *at the same time* as the receiver records the program.

20. Press the **PVR List** button to open the receiver's **PVR Recorded Events** menu on the TV screen.



This menu shows you *everything* you have recorded and stored in the receiver, *plus* what you are recording *right now*.




An “event” is a movie, sports event, show or anything else you can record.

21. Use the remote control **Up/Down/Left/Right** buttons to move the highlight to an event on the **PVR Recorded Events** menu.



22. Press the remote control **Select** button to select the event you highlighted. This opens a menu of information for that event.

*This menu gives you information about the event, plus options like **Start** and **Erase**.*



23. Press the **Cancel** button to go back to the **PVR Recorded Events** menu.



If you want, you can take the time to make some recordings. Once you have done this, you can select a recording to play back *at the same time* as the receiver makes *another* recording.

Using The System Personal Video Recorder (PVR) Quick Tour

3

You can *record* a program at the same time as you *play back* another program!

If you decide to make a recording and play back another recording at the same time, you can use the pause, play, reverse, skip back, forward, or skip ahead features on *either* what you are playing back *or* what you are recording.

You can watch *either* program *any way you* want, while the *receiver* takes care of recording or playing back!

24. Press the **View** button to watch the program you are recording.

or: Press the **Stop** button to stop recording the program.



VIEW



STOP