









## HOW TO USE DOLBY\* DIGITAL SOUND

Dolby Digital lets you use Dolby Surround sound in an audio/video system. To do this, you *must* use an amplifier/decoder that can process Dolby Digital output. The receiver provides a Dolby Digital output, although Dolby Digital sound is *not* available on all programs.

The receiver provides two audio types: Dolby Digital and Linear PCM (regular mono or stereo sound).

	Remote Buttons	Menu Options
1. Press the <b>Menu</b> button.	 	
2. Select the <b>System Setup</b> option.		
3. Select the <b>Dolby Digital</b> option.		
4. Select one of the following options:		
<ul style="list-style-type: none"><li>• <b>Dolby Digital Only</b> - Select this option if the amplifier can process <i>only</i> Dolby Digital (AC3) signals. See the amplifier owner's manual for more details on the amplifier.</li></ul>		
<ul style="list-style-type: none"><li>• <b>PCM Only</b> - Select this option <i>only</i> if the amplifier <i>cannot</i> process Dolby Digital signals.</li></ul>		
<ul style="list-style-type: none"><li>• <b>Dolby Digital/PCM</b> - Select this option <i>only</i> if the amplifier can process <i>both</i> Dolby Digital and Linear PCM signals.</li></ul>		
5. Select the <b>Save</b> option to save the settings.		



The speakers could be damaged if you select the Dolby Digital/PCM option and the amplifier cannot process both types of signals.

\* Trademark of Dolby Laboratories.