

USING THE PROGRAM GUIDE

The on-screen **Program Guide** provides a complete listing of the available channels and programs. You can use the **Program Guide** to change channels, to see what programs are scheduled, and to buy pay per view programs. **Program Guide** shows which **Favourites List** is active.

- The **Program Guide** displays only the channels in the active **Favourites List** (see page 3-13).
- **All Chan** - Displays all of the channels in the **Program Guide**.
- **All Sub** - Displays the channels in your subscription.
- **Favourites Lists** - You can add four **Favourites Lists** that show only the channels you want to see. For more information on creating **Favourites Lists**, see page 3-13.



- A *red* background behind a channel shows that you have not subscribed to that channel. You *cannot* tune in to this channel.
- The **Program Guide** shows programs that are on now and that are scheduled up to two days in advance. The guide does *not* show programs that have ended. You can set up the **Program Guide** to list channels in *ascending* order, with the highest channel number at the top, or in *descending* order, with the highest channel number at the bottom. To do this, open the **Main Menu**. Then, select the **System Setup** option. Finally, select the **Channel Order** option, select the **Ascending** or **Descending** option, and select the **Save** option.
- You can set up the **Program Guide** to hide adult channels. See *Hiding and Unhiding Adult Channels* on page 3-28.
- You can select the rear **RCA AUDIO AND VIDEO** inputs as sub-channels of Channel 1. Select **Channel 1** from the guide, then select either **Input 1** or **Input 2**.

OPENING THE PROGRAM GUIDE

There are two ways to open the **Program Guide**:

- Press the **GUIDE** button.
- Press the **MENU** button and then select the **Program Guide** option.



SELECTING A PROGRAM IN THE PROGRAM GUIDE

Remote
Buttons

Menu Options

1. Use the NUMBER PAD buttons to enter the desired channel number. The **Program Guide** displays a block of channels including the one that you just entered.

2. Use the ARROW buttons to move the highlight to the desired program.

Note: You may press the PAGE UP or PAGE DOWN ARROW button to scan, page by page, through the listing of channels.

3. Press the INFO button for more information about the highlighted program. Press the CANCEL button to return to the **Program Guide**.

4. Press the SELECT button to change to the new channel.

5. You may skip the **Program Guide** forward or backward many hours at one time. To do this, enter the number of hours that you want to skip using the NUMBER PAD buttons. Then press the LEFT or RIGHT ARROW button to move back or forward, respectively. For example: To move forward one day, press numbers 2 and 4, then press RIGHT ARROW.

