

Finding Programs to Watch

WATCHING TV

The receiver is on channel 414, but you want to change the channel to 210. How do you change the channel? You know your team is playing, but you're not sure of the channel. How do you find the game? You're in the mood for a movie, but you don't know which one. Is there a way to look for movies? This chapter shows you the various ways for you to find something to watch.

You'll find the following information in this chapter:

- **CHANGING CHANNELS**
- **USING THE PROGRAM GUIDE**
- **USING THE BROWSE BANNER**
- **USING SEARCH TO FIND A PROGRAM**
- **FINDING A PROGRAM BY ITS THEME**

User Guide

CHANGING CHANNELS


USING THE UP AND DOWN ARROWS

While watching TV, if you want to change the channels one at a time to see what's on, press the UP and DOWN ARROWS on your remote control. You can also change the channels the same way using the UP and DOWN ARROWS on the receiver front panel.



ENTERING A CHANNEL NUMBER

While watching TV, if you know the specific channel you want to watch, enter the channel number using the NUMBER PAD on the remote control.



USING THE PROGRAM GUIDE

You can use the Program Guide to see what programs are on, to change channels, and to set up recordings. To access this guide, press GUIDE.


Active Favourite List

| Channels | 11:00am | 11:30am | 12:00pm |
|-----------|--------------------|----------------|---------------|
| 408 SNET2 | sportsnetnews | sportsnetnews | sportsnetnews |
| 405 SNET1 | sportsnetnews | sportsnetnews | sportsnetnews |
| 402 TSN-5 | Off Air | | |
| 400 TSN | Sportscentre | Off the Record | |
| 399 NHL-N | Classic NHL Hockey | NHL Videos | |

- A red background behind a channel usually means you have not subscribed to the channel. After you subscribe to a channel, you can tune to it. To subscribe to a channel, visit our website at www.bell.ca/selfcare or 1-888-SKY-DISH.
- The Program Guide shows which Favourites List is active. If All Chan is active, the Program Guide shows all the channels. The All Sub list shows only the channels in your subscription. If you activate another list, the Program Guide shows only the channels on that list. See page 5-1 for information on Favourites Lists.
- The Program Guide shows programs on now and coming on within the next two days. The guide does not show programs that have ended.

Finding Programs to Watch Using The Browse Banner

3




While using the Program Banner, you can:


- Press **PAGE UP** or **PAGE DOWN** to move a page of channels at a time.
- Enter the number of hours you want to skip forward or backward in the schedule, and then press the **RIGHT/LEFT ARROW** to move forward or back in the schedule. The Program Guide shows the number of hours.

USING THE BROWSE BANNER

Use the Browse Banner to see what other programs are on and not miss any of a program you are watching. When the Browse Banner is open, you will see the Program Banner information on the current program at the top of the screen, and on the left side of the Browse Banner at the bottom of the screen. At the bottom right of the screen is information on the program that is on next on the same channel.



User Guide




If you select a current program, the receiver will tune to that channel. If you choose a future program, the Create Timer screen will display. See Chapter 8 - Timers on page 8-1 for more information.

USING SEARCH TO FIND A PROGRAM

You can find programs to watch by using the Search feature of the receiver. This feature will search all channels, including and find programs that match keywords that you enter.

USING THE SEARCH FEATURE



You can search for events two ways:

- Select Title to search for the words that appear in the title of a program.
- Select Info to search for words that are in the program description or title.

Finding Programs to Watch

Finding A Program By Its Theme

3

Enter the search word(s) in the Search Criteria Field in one of two ways (see page 2-9):


- Use the virtual keyboard.
- Use the letters on the NUMBER PAD.

If you select a program that is on now, the receiver tunes to that program. If you choose a future program, the Create Timer screen will display. See *Chapter 8 - Timers* on page 8-1 for more information.

USING SEARCH HISTORY


After you have searched previously for programs or other information, your receiver builds a history. You can use the Search History to re-search programming instead of typing the information again.

Note: Use the Edit or Delete options to change or delete Search Keywords.



FINDING A PROGRAM BY ITS THEME

You can list and choose programs by the theme of their contents, for example, just movies or just sports. You can then quickly list programs based on that theme, and choose the program you want.



User Guide

If you select a program that is on now, the receiver tunes to that program. If you choose a future program, the Create Timer screen will display. See *Chapter 8 - Timers* on page 8-1 for more information.

TIPS

- Press INFO to get more information about the program you highlighted.
- Press VIEW LIVE TV to cancel almost any screen and return to viewing TV.
- Skip forward 24 hours (and then back again) at a time in the Program Guide by pressing the SKIP FWD (SKIP BACK) button on the remote control.

QUESTIONS

- **How can I customize the Program Guide to show only my favourite channels?** You can set up a Favourites List as described on page 5-2. You can change how the Program Guide is displayed (size of text, number of programming hours displayed, etc.) as described on page 10-9.
- **Why are some of my channels missing?**
 - You may have locked or hidden the channels. See *Chapter 6 - Locks* on page 6-1 for information on locking and unlocking the receiver.
 - You may have the wrong list showing in the Program Guide. Press Guide to open the Program Guide. Press Guide again to select the next Favourites List. Press Guide repeatedly to scan through all the available lists. See Favourites Lists on page 5-1 for more information.