




TESTING THE SYSTEM

STARTING A TEST

	Remote Buttons	Menu Options
1. Press the Menu button.	MENU 	
2. Select the System Setup option.		
3. Select the Diagnostics option.		

TELEPHONE CONNECTION TEST

This test checks that the receiver telephone connection is correct. Select the Connection option to begin the test. The receiver displays a message asking you to wait until the test is done.

- If the telephone connection is correct, the receiver displays a Phone Connection OK message.
- If the receiver highlights the Dial Out option, the receiver needs to make a toll-free call to the Customer Service Center. Press the remote control Select button to start the call. The receiver displays a message asking you to wait until the call is done. When the call is done, select the Cancel option to exit the test menu.
- If the telephone line is not connected properly, the receiver displays a failure message. In this case, check the telephone connection and then repeat the test.